



NOTE: ALL SAWN LUMBER FLOORS SHALL BE BLOCKED AT 8'-0" O.C. MINIMUM.

SECOND FLOOR FRAMING

FIRST FLOOR FRAMING PLAN

scale